

**Korenix JetPort 5208/5216
Rackmount Serial Device Server**

User's Manual

First Edition, Feb. 2009



www.korenix.com

Korenix JetPort 5208/5216 Rackmount Serial Device Server User's Manual

Copyright Notice

Copyright © 2009 Korenix Technology Co., Ltd.
All rights reserved.

Reproduction in any form or by any means without permission
is prohibited.

Contents

Regulatory Information	ii
RoHS	ii
User Notice	iii
Safety Instructions	iv
General	iv
Rack Mounting	vi
Package Contents	vii
About This Manual	xi
Overview	xi
KORENIX Information	xiii
Technical Support	xiii
Getting Help	xiii
Product Information	xiv

Chapter 1.

Introduction

Overview	1
Requirements	2
Features	3
JETPORT 5208 / JETPORT 5216 Front Panel	5
JETPORT 5208 / JETPORT 5216 Rear Panel	6

Chapter 2.

Hardware Setup

Before you Begin	7
Stacking and Mounting	7
Stacking	7
Rack Mounting	8
PC Installation	9
Sun Fire V100 Server Installation	11

Chapter 3.

Browser Login

Logging In	13
The JETPORT 5208 / JETPORT 5216 Main Screen	14

Chapter 4.

Administration

Working Environment Configuration	15
General	15
Administrator:	16
Connection Control:	16
Network	17
Service Ports:	17

IP Address:	17
ANMS	19
CC Management Settings:	19
RADIUS Settings:	19
SNMP Settings:	21
OOBC	22
Date / Time	23
Firmware	24
Preparation:	24
Starting the Upgrade:	24
Logout	25
Device Management Configuration	26
Port Config	26
Property Settings:	27
Alert Settings:	30
User Management	31
Deleting an Account	32
Adding an Account:	32
Editing an Account:	33
Direct Access	34
Session Info	35
Sys Info	36
Log	37

Chapter 5.

Browser Operation

Overview	39
Telnet	41
Port Configuration	45
User Manager	45

Chapter 6.

Out of Band Operation

Overview	47
HyperTerminal	47
Direct HyperTerminal Connection	47
Logging In:	51
Indirect HyperTerminal Connection	52
Final Check:	53
Logging In	54
PPP (Dial In) Connection	55
Direct PPP Connection	55
Finishing Up:	58
Logging In:	58
Indirect PPP Connection	59
Setup:	59

Final Check:	60
Logging In:	60
Telnet	61
Logging In	61
SSH	62
Terminal Session (Linux):	62
Third Party Utility (Windows):	63

Chapter 7.

Real Port Management

Overview	65
Driver Installation	65
Real Port Management	66
Dialog Box Layout	66
Menu and Toolbar	67
Target Information	67
Target List	68
Port List	69
Mapped COM Ports	70
Port Mapping and Unmapping	71
Port Mapping	71
Port Unmapping	72

Appendix

Specifications	73
Administrator Login Failure	74
IP Address Determination	75
Method 1:	75
Method 2:	76
Method 3:	77
RJ-45 to Serial Adapters	78
Troubleshooting	82
Battery Replacement	82
Limited Warranty	82

Overview

Chapter 1, Introduction, introduces you to the JETPORT 5208 / JETPORT 5216 System. Its purpose, features and benefits are presented, and its front and back panel components are described.

Chapter 2, Hardware Setup, provides step-by-step instructions for setting up your installation.

Chapter 3, Browser Login, explains how to log into the JETPORT 5208 / JETPORT 5216 from your browser.

Chapter 4, Administration, explains the administrative procedures that are employed to configure the JETPORT 5208 / JETPORT 5216's working environment.

Chapter 5, Browser Operation, details concepts and procedures involved in the browser operation of your JETPORT 5208 / JETPORT 5216 installation.

Chapter 6, Out of Band Operation, describes how to set up the various serial port methods that can be used to access the JETPORT 5208 / JETPORT 5216 when the network is unavailable.


Chapter 7, Real Port Management, shows how to install the Real COM port driver and to set up and manage the Real COM ports.

An Appendix, at the end of the manual provides technical and troubleshooting information.

Overview

The JETPORT 5208 / JETPORT 5216 Serial over the net is a control unit that provides both In-Band and Out-of-Band remote serial access to up to 8 (JETPORT 5208) or 16 (JETPORT 5216) servers or other serial IT devices (hubs, routers, power management devices, etc.), via a Telnet or SSH TCP/IP connection.

Up to 8 (JETPORT 5208) or 16 (JETPORT 5216) Users can log in at the same time from any computer connected to the Internet, whether down the hall, or half way around the world. Each is able to control a separate port so that eight attached devices can be accessed at the same time.



The JETPORT 5208 / JETPORT 5216 can work in tandem with other remote management products. Management system to provide convenient, reliable, and effective, remote data center device management.

Installation is fast and easy: plugging cables into their appropriate ports is all that is entailed. A choice of browser based GUI, Telnet (SSH), and VT console terminal sessions make configuration and operation smooth and convenient.

The JETPORT 5208 / JETPORT 5216's firmware is upgradeable over the Net, so you can stay current with the latest improvements simply by downloading updates from our website. With its advanced features and ease of operation, the JETPORT 5208 / JETPORT 5216 is the most convenient, most reliable, and most cost effective way to centrally manage your remote, serially connected, IT products.

Requirements

- § Sun's Java 2 JRE 1.4.2 or higher must be installed on your computer. Java is available for free download from the Sun Java website:
`http://java.sun.com`
- § The devices that connect to the JETPORT 5208 / JETPORT 5216 must support the RS-232 protocol or RS-232 terminal operations
- § Real COM port driver (Real COM port) support requires Windows 2000 or higher.

Features


JetPort 5216

- 16 ports RS-232 over 10/100M Ethernet
- Real COM Driver for Windows 2000/XP/2003/Vista, Linux
- Versatile Serial Services: Real Com, TCP server.
- Multi-level secure user authentication and authorization by SSH / Telnet or Console
- Auto IP Discovery, and Virtual Port Mapping Utility
- User Access by Port
- Dial-in Modem and direct Access by PPP/Hyper Terminal
- Choice of configuration methods: Web console, console terminal.
- SNMP MIB II, RS-232 MIB for network management, SNMP Trap
- Event Notification by Syslog, E-mail, and SNMP trap
- Standard 19-inch rack mount 1U size

JetPort 5208



- 8 ports RS-232 over 10/100M Ethernet
- Real COM Driver for Windows 2000/XP/2003/Vista, Linux
- Versatile Serial Services: Real Com, TCP server.
- Multi-level secure user authentication and authorization by SSH / Telnet or Console
- Auto IP Discovery, and Virtual Port Mapping Utility
- User Access by Port
- Dial-in Modem and direct Access by PPP/Hyper Terminal
- Choice of configuration methods: Web console, console terminal.
- SNMP MIB II, RS-232 MIB for network management, SNMP Trap
- Event Notification by Syslog, E-mail, and SNMP trap
- Standard 19-inch rack mount 1U size

JETPORT 5208 / JETPORT 5216 Front Panel



No.	Component	Description
1	Port LEDs	A Port LED lights to indicate the device attached to its corresponding port is online. The LED flashes when data is being transmitted through its corresponding port.
2	Reset Switch	Pressing and holding this switch in for less than three seconds performs a system reset. Pressing and holding this switch in for more than three seconds returns its settings to their default status.
3	10/100 Mbps Data LED	The LED lights ORANGE to indicate a 10 Mbps data transmission speed. It lights GREEN to indicate a 100 Mbps data transmission speed.
4	Link LED	Flashes GREEN to indicate that a Client program is accessing the device.
5	Power LED	Lights when the JETPORT 5208 is powered up and ready to operate.

JETPORT 5208 / JETPORT 5216 Rear Panel



No.	Component	Description
1	Power Socket	The power cable from the AC source plugs in here.
2	Power Switch	This is a standard rocker switch that powers the JETPORT 5208/ JETPORT 5216 on and off.
3	LAN Port	The Ethernet cable that connects the JETPORT 5208 / JETPORT 5216 to the Internet plugs in here.
4	Serial Ports	The RJ45 to Serial Cable

Chapter 2 Hardware Setup

Before you Begin




1. Make sure that power to all the devices you will be connecting up have been turned off.

Stacking and Mounting

The JETPORT 5208 / JETPORT 5216 can be placed on the desktop or it can be rack mounted, as described in the sections that follow.

Stacking


To place the JETPORT 5208 / JETPORT 5216 on the desktop stick the self-adhesive footpads that came with your package to the unit's bottom panel at the four corners.




Rack Mounting

The JETPORT 5208 / JETPORT 5216 can be mounted in a 1U system rack. The mounting brackets can screw into either the front or the back of the unit so that it can attach to the front or the back of the rack. To rack mount the unit:

1. Remove the screws at the front or the rear, as shown in the diagram below.



2. Screw the mounting brackets into the sides of the unit at the front or the rear, as shown in the diagram below.



3. Slide the unit into the front or rear of the rack and secure it to the rack.

PC Installation

Refer to the Installation Diagram on p.10 (the numbers in the diagram correspond to the numbers of the steps), as you do the following:


1. For each server or serial device, plug an *RJ45 to Serial cable* into its serial port.
2. Plug the RJ-45 connector of the cable above to connect any available port on the JETPORT 5208 / JETPORT 5216's rear panel to the adapter.
3. If you choose to install a serial modem for OOB operation (see Chapter 6), use standard Ethernet cable to connect any available port on the JETPORT 5208 / JETPORT 5216's rear panel to a DTE to DCE serial Cable then plug the cable into the modem's serial port.

Note: This step is optional.

4. Plug a Ethernet cable to connects the JETPORT 5208 / JETPORT 5216 to the network or the Internet into its LAN port.
5. Use the AC power cord provided with this package to connect the JETPORT 5208/ JETPORT 5216's Power Socket to an AC power source.

After you connect all the cables, you can turn on the JETPORT 5208 / JETPORT 5216.

PC Installation Diagram:



Sun Fire V100 Server Installation

For each Sun Fire V100 server you wish to install, refer to the Installation Diagram on p. 12 (the numbers in the diagram correspond to the numbers of the steps), as you do the following:


1. Use standard Ethernet cable to connect any available port on the JETPORT 5208 / JETPORT 5216's rear panel.
2. Use standard Ethernet cable to connect the V100's LAN port.

Note: If you choose to install a serial modem for OOB operation (see Chapter 6), refer to step 3 of the PC installation procedure.

4. Plug the cable that connects the JETPORT 5208 / JETPORT 5216 to the network or the Internet into its LAN port.
5. Use the AC power cord provided with this package to connect the JETPORT 5208 / JETPORT 5216's Power Socket to an AC power source.

After you connect all the cables, you can turn on the JETPORT 5208 / JETPORT 5216.

Sun Fire V100 Server Installation Diagram



Chapter 3

Browser Login

Logging In

JETPORT 5208 / JETPORT 5216 operation is Internet browser based. To begin:

1. Open your browser and specify the IP address of the JETPORT 5208 / JETPORT 5216 you want to access in the browser's URL location bar.

Note: 1. Default IP: 192.168.10.2

2. If you are the administrator, and are logging in for the first time, the various ways to determine the JETPORT 5208 / JETPORT 5216's IP address are described in the Appendix on p. 75.
-
2. A *Security Alert* dialog box appears. Accept the certificate.
 3. A login dialog box, like the one below, appears:




The image shows a screenshot of a web browser login dialog box. The title bar at the top reads "JetPort5208 - Login". Below the title bar, there are two text input fields. The first is labeled "Username:" and the second is labeled "Password:". At the bottom of the dialog box, there are two buttons: "Login" and "Reset".

4. Provide a valid Username and Password (set up by the administrator), then Click **Login** to continue.

Note: If you are the administrator, and are logging in for the first time, use the **default Username: admin**; and the **default Password: admin**. For security purposes, we strongly recommend you remove these and give yourself a unique Username and Password.

The JETPORT 5208 / JETPORT 5216 Main Screen

After you have successfully logged in, the Main Screen appears:



§ Except for the *Logout* icon, the icons arranged horizontally across the top are only enabled for the administrator. Administrative functions are explained in Chapter 4.

Note: Be sure to click the *Logout* icon when you end your session.

§ The bar along the left side is used to configure and control access to each of the JETPORT 5208 / JETPORT 5216's COM ports. The functions of each of the buttons is described in Chapter 5.

§ Unless you need to perform administrative functions, you can skip to Chapter 5 now.

Chapter 4 Administration

Working Environment Configuration


The icon bar at the top of the main screen is used by the administrator to configure the JETPORT 5208 / JETPORT 5216's working environment.



An explanation of each of the configuration functions is given in the sections that follow.

General

When you click the *General* icon, the following dialog box appears:

A dialog box titled "General Settings" with a black header. It contains three sections: "System Information" with fields for "Station Name" (containing "JetPort5208") and "Station Description" (a text area); "Administrator" with fields for "Name" (containing "administrator"), "Old Password", "Password", "Confirm Password", and "Comments" (a text area); and "Connection Control" with a "Session timeout" field set to "3" minutes. At the bottom are "Save" and "Restore" buttons.

General Settings	
System Information	
Station Name:	<input type="text" value="JetPort5208"/>
Station Description:	<input type="text"/>
Administrator	
Name:	<input type="text" value="administrator"/>
Old Password:	<input type="text"/>
Password:	<input type="text"/>
Confirm Password:	<input type="text"/>
Comments:	<input type="text"/>
Connection Control	
Session timeout:	<input type="text" value="3"/> min. (0:Disable)
<input type="button" value="Save"/> <input type="button" value="Restore"/>	

The dialog box is divided into three main panels, as described below:

System Information:

The System Information section allows you to provide a name and description for the JETPORT 5208 / JETPORT 5216 Station. Providing a Station Name and Station Description is optional, but makes it convenient to differentiate the Stations in large, multistation installations.

Administrator:

This section sets the administrator's login name and password.

§ The default administrator name is: *admin*

§ The default password is: *admin*

For security purposes, we strongly recommend that you change the default values to something unique.

The *Comments* field is optional. It provides administrators with a place to enter personal comments.

Connection Control:

Session Timeout sets a timeout value. If there is no input from the logged in operator for the amount of time set with this function, the operator is automatically logged out and the session is terminated. Valid settings are from 0 ~ 255 minutes. A setting of 0 (zero) disables this function. The default is 3 minutes.

Network

Network Configuration allows you to set up the network parameters for the JETPORT 5208 / JETPORT 5216:

Network Configuration	
Service Ports:	HTTP: 80
	HTTPS: 443
	Telnet: 23
	SSH: 22
	Socket: 5001 Base socket for OCMs
<input type="checkbox"/> Obtain an IP address automatically (DHCP)	
Primary IP:	10.0.0.163
Primary Subnet Mask:	255.255.255.0
Gateway:	10.0.0.3
Primary DNS Server:	
Alternate DNS Server:	
<input type="checkbox"/> Enable report to the following address	
SMTP Server:	
<input checked="" type="checkbox"/> My server requires authentication	
Account Name:	
Password:	
From:	
To:	
<input type="button" value="Update"/>	

Service Ports:

Lets you select the service ports that the JETPORT 5208 / JETPORT 5216 listens for incoming data on. Unless you have a specific reason for changing them, we recommend you leave the default settings as they are.

IP Address:

The default is for a fixed IP address. To give the JETPORT 5208 / JETPORT 5216 a fixed IP address, fill in the *Primary IP* to *Alternate DNS Server* fields with values appropriate to the network you are on.

Default IP address is 192.168.10.2

To have the Station obtain its IP address automatically from a DHCP server:

1. Put a check in the *Obtain an IP address automatically [DHCP]* checkbox.
2. Enable the *Enable report from the following SMTP server* checkbox, and key in the IP address of your SMTP server.
3. If your server requires authentication, put a check in the *My server requires authentication* checkbox.
4. Key in the appropriate account information in the *Account Name*, *Password*, and *From* fields.
5. Key in the email address of where you want the report of the DHCP address sent to in the *To* field.
6. When all of your configuration settings have been made, click **Update** to save the information and have the JETPORT 5208 / JETPORT 5216's DHCP generated IP address emailed to you.

Note: If the JETPORT 5208 / JETPORT 5216 is on a network that uses DHCP to assign network addresses, and you don't know what the address is, there are several methods you can use to ascertain it..

ANMS

The Authentication Network Management Service dialog box allows you to set up login authorization management from external sources. It is divided into three main panels, as described below:

Authentication Network Management Service	
CC Management Settings	
<input type="checkbox"/> Enable CC Management	
CC Server IP:	192.168.0.100
CC Server Port:	8889
RADIUS Settings	
<input type="checkbox"/> Enable RADIUS	
Primary RADIUS Server IP:	192.168.0.100
Primary RADIUS Service Port:	1812
Alternate RADIUS Server IP:	192.168.0.100
Alternate RADIUS Service Port:	1645
Shared Secret:	Secret (6 characters min.)
Timeout:	3 (seconds)
Retries:	3
SNMP Settings	
<input type="checkbox"/> Enable SNMP Agent	
<input checked="" type="checkbox"/> Enable SNMP Trap	
Community Name for Read:	public
Community Name for Write:	private
Community Name for Trap:	public
SNMP Manager 1:	192.168.0.100
SNMP Manager 2:	
SNMP Manager 3:	
SNMP Manager 4:	
Save	

RADIUS Settings:

If you want to allow authorization for the JETPORT 5208 / JETPORT 5216 through a

RADIUS server, do the following:

1. Check *Enable RADIUS*.
2. Fill in the IP addresses and Service Ports for the Primary and Alternate RADIUS servers.
3. Key the *Shared Secret* character string that you want to use for authentication between the JETPORT 5208 / JETPORT 5216 and the RADIUS Server.

4. Set the time in seconds that the JETPORT 5208 / JETPORT 5216 waits for a RADIUS server reply before it times out in the Timeout field.
5. Set the number of RADIUS retries allowed in the Retries field.
6. Click **Save** to save the information.
7. On the RADIUS server, set the access rights for each user according to the attribute information in the table, below:

Attribute	Meaning
U	(User) The user has the authority to access and configure some ports. This attribute must be specified for all users who access the system.
T	(True) The user has the authority to access and configure the ports that are specified with it.
F	(False) The user cannot configure any ports.
A	(All) The user has the authority to access and configure all ports.

Example:

U,T,2,3,5,6,12,16

The user can access and configure ports 2, 3, 5, 6, 12, and 16.

-
- Note:**
1. The characters are not case sensitive. Upper or lower case work equally well.
 2. Characters are comma delimited.
 3. An invalid character in the string will prohibit access to the JETPORT 5208 / JETPORT 5216 for the user.

SNMP Settings:

If you want to use SNMP to help with your installation management:


1. Check *Enable SNMP Agent*.
2. Once SNMP Agent has been enabled, the *SNMP Trap* checkbox becomes active. If you want to enable SNMP trapping, click to put a check in the checkbox.
3. Key in passwords for the *Community Name* fields. We recommend replacing the defaults (public, private) with an alphanumeric string of at least 8 characters.
4. Key in the IP addresses of the computers that will automatically be notified of SNMP trap events in the *SNMP Manager* fields.
5. When you have finished making all your entries, click **Save**, to save them.

Note: MIB definitions for the JETPORT 5208 / JETPORT 5216 are provided on the CD that came with this package.

OOBC

OOBC (Out of Band Configuration), provides the ability to access the JETPORT 5208 / JETPORT 5216 via a serial connection. This can either be a direct serial connection from a local computer, or a dial in connection via modem.

When you click the *OOBC* icon, the following dialog box appears:



Out of Band Configuration	
Console Port:	COM1
Server IP:	192.168.0.1
Client IP:	192.168.0.2
Subnet Mask:	255.255.255.0
Update	

1. Select which port will be used for the Console Port. The Console Port is the one that you connect the terminal or modem to for OOB communication. The default is Port 1 (COM1), but you can use any of the ports as long as you specify which one it is, here.
2. Specify the JETPORT 5208 / JETPORT 5216's IP address in the *ServerIP* field.
3. Specify the IP address of the device that will connect to the JETPORT 5208 / JETPORT 5216 in the *ClientIP* field.
4. Click **Update** to save the information.

The various ways to access the JETPORT 5208 / JETPORT 5216 with an OOB connection, are described in Chapter 6.

Date / Time

The Date / Time function allows you to set the JETPORT 5208 / JETPORT 5216's date and time. When you click the *Date / Time* icon, the following dialog box appears:

The date and time that the JETPORT 5208 / JETPORT 5216 is currently set to appear in the upper section. The large lower section offers three methods to set new date and time parameters:

- § Synchronizing the date and time with your computer's date and time
- § Setting the date and time manually
- § Synchronizing the date and time with the date and time of an NTP server on the internet

Note: 1. If you enable *Synchronize with computer time*, the Date and Time fields are filled with the date and time settings of your computer.

2. If you enable Set Manually, key in the Date and Time in the corresponding fields.

3. If you enable Synchronize with NTP server, select the time zone that corresponds to the JETPORT 5208 / JETPORT 5216's location from the list box in the Time Zone panel. If you are behind a firewall, you must enable a port for the NTP server.

- § Click **Save** to save your changes.

Firmware


The Firmware Upgrade function provides a smooth, automated process for upgrading the JETPORT 5208 / JETPORT 5216's firmware. New firmware upgrade packages are posted on our web site as they become available. Check the site regularly to find the latest packages.

Preparation:

1. From your computer, go to our Internet support site and choose the model name that relates to your product (JETPORT 5208 / JETPORT 5216) to get a list of available Firmware Upgrade Packages.
2. Choose the Firmware Upgrade Package you want to install (usually the most recent), and download it to your computer.

Starting the Upgrade:

1. From the computer that you downloaded the upgrade file to, log into the JETPORT 5208 / JETPORT 5216.
2. Click the *Firmware* icon. A dialog box similar to the one below appears:



3. Click the *Browse* button; navigate to the upgrade file on your computer, and select it.
4. Click **Upgrade** to perform the upgrade.

Note: 1. If you enable *Check Firmware Version*, the upgrade function compares the station's firmware level with that of the upgrade files. If it finds that the JETPORT 5208 / JETPORT 5216's current version is equal to, or higher than, the upgrade version, it won't overwrite the JETPORT 5208 / JETPORT 5216's version.

2. If you do not enable Check Firmware Version, the Utility installs the upgrade files without checking whether they are a higher level, or not.
-

Logout

Click the *Logout* icon to end your JETPORT 5208 / JETPORT 5216 session.

Device Management Configuration

The buttons in the bar along the left side of the JETPORT 5208 / JETPORT 5216 web page are used to manage and access the devices connected to the JETPORT 5208 / JETPORT 5216's COM ports.

This section discusses the functions available to administrators and, in the case of port configuration, users with configuration permission. The functions available to ordinary users are discussed in Chapter 5, *Browser Operation*.

Port Config

The administrator and users with port configuration permission, can set up the operating parameters for each of the JETPORT 5208 / JETPORT 5216's ports by clicking the *Port Config* button to bring up the Port Configuration dialog box:

Port Configuration			
Select	Port Number	Port Name	TCP Port
<input checked="" type="radio"/>	COM1	Console	-
<input type="radio"/>	COM2	COM2	5002
<input type="radio"/>	COM3	COM3	5003
<input type="radio"/>	COM4	COM4	5004
<input type="radio"/>	COM5	COM5	5005
<input type="radio"/>	COM6	COM6	5006
<input type="radio"/>	COM7	COM7	5007
<input type="radio"/>	COM8	COM8	5008
<input type="radio"/>	COM9	COM9	5009
<input type="radio"/>	COM10	COM10	5010
<input type="radio"/>	COM11	COM11	5011
<input type="radio"/>	COM12	COM12	5012
<input type="radio"/>	COM13	COM13	5013
<input type="radio"/>	COM14	COM14	5014
<input type="radio"/>	COM15	COM15	5015
<input type="radio"/>	COM16	COM16	5016

Property Settings:

To set up the serial communications parameters for a port, select it, then click the *Property Settings* button at the bottom of the page:

Port Configuration	
Port ID:	COM2
Port Name:	COM2
Baud Rate:	9600 bps
Data Bits:	8 bits
Parity:	None
Stop Bits:	1 bit
Flow Control:	None
Enable Toggle DTR:	No
Online Detect:	DSR
Out CRLF Translation:	None
Suspend Character:	D
Operating Mode:	Console Management
Timeout:	3 minute(s)
Authorized Operators:	administrator
Update	

The meanings of the settings are given in the following table:

Setting	Meaning
Port ID	Each port on the JETPORT 5208 / JETPORT 5216 has a port ID number (COM1 - COM8 for the JETPORT 5208, or COM1 - COM16 for the JETPORT 5216). The Port ID field displays the number of the port that is being configured.
Port Name	You can give a port an appropriate name by editing the <i>Port Name</i> field.
Serial Parameters (Data Bits - Out CRLF Translation)	The serial parameter fields allow you to set up the port so that the JETPORT 5208 / JETPORT 5216 can communicate with the device connected to it. Choose the parameters so that they match the ones for the connected device.
Suspend Character	The <i>Suspend character</i> is used to bring up the Suspend Menu in Telnet sessions.

(Continues on next page.)

(Continued from previous page.)

Setting	Meaning
Operating Mode	<p>The choices are:</p> <p>Console Management: In this mode, users establish a Telnet or SSH session under the JETPORT 5208 / JETPORT 5216 to manage a server or serial device connected to the port. Users can log in using the browser Telnet function, a direct Telnet session, SSH or PuTTY. This mode can also be used for Out-of-Band operation via the JETPORT 5208 / JETPORT 5216's Console Port. See <i>Out of Band Operation</i>, Chapter 6.</p> <p>Raw TCP Mode: This mode is used with socket programming to directly control the device's data transmission without the need for serial port control or serial modem signal control. Only data is transmitted (using IP as the protocol).</p> <p>Note: When you use the IP address you must also specify the port number. For example: 192.168.0.200 5003.</p> <p>For security purposes, access to the port can be limited to specific IP addresses. See <i>Direct Access</i></p> <p>Real COM Port: Used with a Real COM port driver on the local machine (See <i>Real Port Management</i>, Chapter 7 for Real port management details.) The device connected to this port appears as if it were a device directly connected to a COM port on the local computer. Data transmission between the device and the local computer takes place over the Real COM port to the JETPORT 5208 / JETPORT 5216.</p> <p>This mode is useful with serial devices such POS terminals, Bar Code Readers, Serial printers, etc.</p> <p>As with Raw TCP Mode, access to the port can be limited to specific IP addresses with the <i>Direct Access</i> function.</p>

(Continues on next page.)

(Continued from previous page.)

Setting	Meaning
Timeout	If there is no input on this port for the amount of time set with this function, the port is released for use by another user. Note: This field doesn't appear when this dialog box is accessed from the Console port.
Authorized Operators	The <i>Authorized Operators</i> field indicates the users that are authorized to operate the port. The information in this field is for viewing purposes only. It can't be changed on this page.

- § When you have finished making your settings choices, click **Update** to save them.
- § To abandon the settings choices without saving them, simply leave the page.

Alert Settings:

The Port Alert Settings dialog box provides a way for you to be informed via email about problems that may occur on the devices connected to the JETPORT 5208

/ JETPORT 5216's ports. When a device has a problem - such as a critical error that requires a reboot - debug messages can be sent through its COM port.

When the JETPORT 5208 / JETPORT 5216 receives such a message, it can send an email to inform the user specified here of the problem.

You can have up to 10 types of alert emailed to you when a device generates them. To configure a port to provide alert notification, select it in the *Select* column, then click the *Alert Settings* button. A dialog box, similar to the one below, appears:

Port Alert Configuration	
Port ID:	COM1
Alert String 1:	<input type="text"/>
Alert String 2:	<input type="text"/>
Alert String 3:	<input type="text"/>
Alert String 4:	<input type="text"/>
Alert String 5:	<input type="text"/>
Alert String 6:	<input type="text"/>
Alert String 7:	<input type="text"/>
Alert String 8:	<input type="text"/>
Alert String 9:	<input type="text"/>
Alert String 10:	<input type="text"/>
<input type="checkbox"/> Enable report from the following SMTP Server	
SMTP Server:	<input type="text"/>
<input type="checkbox"/> My server requires authentication	
Account Name:	<input type="text"/>
Password:	<input type="text"/>
From:	<input type="text"/>
To:	<input type="text"/>
Update	

1. Use the *Alert String* fields to specify the alerts you want to receive.
2. Enable the *Enable report to the following address* checkbox, and key in the IP address of your SMTP server.
3. If your server requires authentication, put a check in the *My server requires authentication* checkbox.
4. Key in the appropriate account information in the *Account Name*, *Password*, and *From* fields.
5. Key in the email address of where you want the report sent to in the *To* field.
6. When all of your configuration settings have been made, click **Update** to save the information.

After setting up this page, whenever one of the specified alerts is generated, you will be informed by email of its occurrence.

User Management

Clicking the *User Manager* button brings up the User Management dialog box. If this is the first time you are accessing this function, and no user accounts have been created yet, the following screen displays:



Click **New** to begin setting up user accounts. See p. 32 for adding, editing, and deleting user accounts.

If user accounts have been set up, the User Manager dialog box appears:

User Manager			
Select	Login Name	Config	Ports
<input checked="" type="radio"/>	frosty	Enabled	All
<input type="radio"/>	rjf111	Disabled	2,3,4,5,6,7,10,11,14
<input type="radio"/>	fernando	Disabled	9,10,11,12,13,14,15,16
<input type="radio"/>	jessica	Enabled	All

This dialog box allows the administrator to add, delete, and edit user accounts. Up to 15 user accounts can be established. Operators must provide the Usernames and Passwords established here, in order to log in.

Deleting an Account

To delete a user account, select it and click **Delete**.

Adding an Account:

To add a user, click **Add**. A dialog box similar to the one below appears:

User Information				
Username:	<input type="text"/>	Comments:	<input type="text"/>	
Password:	<input type="text"/>	Reenter password:	<input type="text"/>	
<input type="checkbox"/> Port Config Permission				
Enable	Port Number	Port Name	Tcp Port	Shared
<input checked="" type="checkbox"/>	COM2	COM2	5002	Yes
<input checked="" type="checkbox"/>	COM3	COM3	5003	Yes
<input checked="" type="checkbox"/>	COM4	COM4	5004	Yes
<input checked="" type="checkbox"/>	COM5	COM5	5005	Yes
<input checked="" type="checkbox"/>	COM6	COM6	5006	Yes
<input checked="" type="checkbox"/>	COM7	COM7	5007	Yes
<input checked="" type="checkbox"/>	COM8	COM8	5008	Yes
<input checked="" type="checkbox"/>	COM9	COM9	5009	Yes
<input checked="" type="checkbox"/>	COM10	COM10	5010	Yes
<input checked="" type="checkbox"/>	COM11	COM11	5011	Yes
<input checked="" type="checkbox"/>	COM12	COM12	5012	Yes
<input checked="" type="checkbox"/>	COM13	COM13	5013	Yes
<input checked="" type="checkbox"/>	COM14	COM14	5014	Yes
<input checked="" type="checkbox"/>	COM15	COM15	5015	Yes
<input checked="" type="checkbox"/>	COM16	COM16	5016	Yes

1. Key in the user's Username and Password (up to 16 characters for each).
2. Reenter the password to confirm that it is correct.
3. Key in any Comments you wish to make concerning the user. (optional)
4. If you want the user to have Port Configuration permission, put a check in the *Port Config Permission* checkbox. Otherwise, leave it blank.

Note: 1. *Port Configuration* is where the Port Numbers and Names that appear in this dialog are set. See *Port Config*, for port configuration information.

2. The term "Yes" in the *Shared* column means that other users have access permission to the port.
-

5. If there are any ports that you do not want the user to access, remove the check from the *Enable* checkbox.
6. Click **Add** to save your changes.

Editing an Account:

1. To Edit a user account click **Edit**. A dialog box similar to the one below appears:

User Information				
Username:	frosty		Comments:	
Password:			Reenter password:	
<input checked="" type="checkbox"/> Port Config Permission				
Enable	Port Number	Port Name	Tcp Port	Shared
<input checked="" type="checkbox"/>	COM2	COM2	5002	Yes
<input checked="" type="checkbox"/>	COM3	COM3	5003	Yes
<input checked="" type="checkbox"/>	COM4	COM4	5004	Yes
<input checked="" type="checkbox"/>	COM5	COM5	5005	Yes
<input type="checkbox"/>	COM6	COM6	5006	Yes
<input checked="" type="checkbox"/>	COM7	COM7	5007	Yes
<input type="checkbox"/>	COM8	COM8	5008	Yes
<input checked="" type="checkbox"/>	COM9	COM9	5009	Yes
<input type="checkbox"/>	COM10	COM10	5010	Yes
<input checked="" type="checkbox"/>	COM11	COM11	5011	Yes
<input checked="" type="checkbox"/>	COM12	COM12	5012	Yes
<input checked="" type="checkbox"/>	COM13	COM13	5013	Yes
<input type="checkbox"/>	COM14	COM14	5014	Yes
<input checked="" type="checkbox"/>	COM15	COM15	5015	Yes
<input type="checkbox"/>	COM16	COM16	5016	Yes
Update		Back		

2. Make your changes in the appropriate fields and checkboxes.
3. To save your changes, click **Update**.
4. To exit without saving any changes, click **Back**.

Direct Access

For security purposes, *Direct Access* can limit the users attempting to log in to ports that have been specified as *RAW TCP Port*.

Direct Access IP Configuration	
IP 01:	<input type="text"/>
IP 02:	<input type="text"/>
IP 03:	<input type="text"/>
IP 04:	<input type="text"/>
IP 05:	<input type="text"/>
IP 06:	<input type="text"/>
IP 07:	<input type="text"/>
IP 08:	<input type="text"/>
IP 09:	<input type="text"/>
IP 10:	<input type="text"/>
IP 11:	<input type="text"/>
IP 12:	<input type="text"/>
IP 13:	<input type="text"/>
IP 14:	<input type="text"/>
IP 15:	<input type="text"/>
IP 16:	<input type="text"/>
IP 17:	<input type="text"/>
IP 18:	<input type="text"/>
IP 19:	<input type="text"/>
IP 20:	<input type="text"/>
IP 21:	<input type="text"/>
IP 22:	<input type="text"/>
IP 23:	<input type="text"/>
IP 24:	<input type="text"/>
IP 25:	<input type="text"/>
IP 26:	<input type="text"/>
IP 27:	<input type="text"/>
IP 28:	<input type="text"/>
IP 29:	<input type="text"/>
IP 30:	<input type="text"/>
IP 31:	<input type="text"/>
IP 32:	<input type="text"/>




If no IP addresses are specified on this page, anyone can open a TCPIP Telnet session to a RAW TCP port by specifying the IP address and port number of the port – without having to specify a Username and Password.

Once specific IP addresses are entered here, however, only users logging in to the JETPORT 5208 / JETPORT 5216 from one of those IP addresses can have access to the RAW TCP ports without having to specify a Username and Password.

Note: The port must be designated as a *RAW TCP Port* under the *Port Config* settings. See *Operating Mode*.

Session Info


Clicking the *Session Info* button brings up the Active Sessions display:

Active Sessions								
Select	Login Name	Local User	Admin	Port	Service	IP	UP Time	Last Access
	admin	Yes	Yes	Local	HTTPS	10.0.0.58	18:29:46	18:29:47
	admin	Yes	Yes	Local	HTTPS	10.0.1.152	19:38:33	19:38:55
	rjfl	Yes	-	Local	HTTPS	10.0.1.97	20:27:01	20:27:34

This display lets the administrator see at a glance all the users currently logged into the JETPORT 5208 / JETPORT 5216, and provides information about each of their sessions. It also gives the administrator the option of forcing a user logout by selecting the user and clicking **End Session**.


Sys Info

The System Information dialog box provides information about all aspects of the JETPORT 5208 / JETPORT 5216's configuration:



Log

Clicking the *Log* button brings up the Event Log dialog box:



Event Log		
<input checked="" type="radio"/> Today	<input type="radio"/> All	<input type="radio"/> Selected
From : (YYYY/MM/DD)	2004/08/20	
To : (YYYY/MM/DD)	2004/08/20	
OK		


The JETPORT 5208 / JETPORT 5216 maintains a log file of the events that take place on it. This dialog box allows you to select the range of events you wish to view:

- § Choose **Today** then click **OK** to see a listing of only today's events.
- § Choose **All** then click **OK** to see a listing of events for the entire log file.
- § Choose **Selected**; key in the desired range of dates in the *From* and *To* fields; then click **OK** to see a listing of events for a specific time period.

Note: The maximum number of events contained in the log file is 512. Once that amount is reached, the oldest events are discarded as new ones are recorded.

(Continues on next page.)

Once you make a choice and click OK an Event Log List, similar to the one below, appears:



When you have finished viewing the event list:





- § If you want to return to the Event Log dialog box, click **Back**.
- § If you want to erase the contents of the entire log file, click **Clear All**.
- § To exit, select a different function from the button bar.

Chapter 5

Browser Operation





Overview

Once you have logged in and the Main Screen appears (see *The JETPORT 5208 / JETPORT 5216 Main Screen*). The bar along the left side is used to configure and control access to each of the JETPORT 5208 / JETPORT 5216's COM ports. The functions of each of the buttons is described in the following table:

Button	Authorization	Function
	All	Clicking this button brings up the Serial Port Status screen. This is the same screen that displays after a log in. Users can see the status of each of the devices attached to the JETPORT 5208 / JETPORT 5216's COM ports.
	All	Clicking this button brings up the Telnet page. This page allows the administrator and all users to open telnet sessions to connect to the devices attached to the JETPORT 5208 / JETPORT 5216's COM ports. See p. 41 for details.
	Administrator and Permitted Users	This page allows the administrator and users with configuration permission, to set up the COM port parameters for each of the JETPORT 5208 / JETPORT 5216's COM ports
	All	<p>This button has two effects depending on whether the administrator or an ordinary user clicks it:</p> <ul style="list-style-type: none"> § The administrator can use this function to Create, Edit, and Delete user profiles § Ordinary users can only use this function to change their passwords and personal information <p>Note: Operators who have logged in via a RADIUS server can view User Manager information, but cannot make any changes to that information.</p>

(Continues on next page.)

(Continued from previous page.)

Button	Authorization	Function
	Administrator Only	For security purposes, Direct Access can limit the users attempting to log in to ports that have been specified as RAW TCP Ports and Real COM Ports.
	Administrator Only	This page allows the administrator to see information about all the users who are currently logged into the JETPORT 5208 / JETPORT 5216.
	Administrator Only	This page shows information about the JETPORT 5208 / JETPORT 5216's configuration.
	Administrator Only	Clicking this button brings up the <i>Event Log</i> dialog box which allows the administrator to view all of the events that took place on the JETPORT 5208 / JETPORT 5216 (see p. 37 for details).

- Note:**
- Buttons are only active for the functions that the user is authorized to perform.
 - Administrator functions (including *Port Config*) are discussed in Chapter 4.
 - The *Telnet*, and *User Manager* operations are discussed in the sections that follow.
-

Telnet

After viewing the status of the devices attached to the JETPORT 5208 / JETPORT 5216's ports, if you want to access any of them, click the **Telnet** button. A screen similar to the one below appears:

Telnet Selection			
Select	Port Number	Port Name	TCP Port
<input checked="" type="radio"/>	Local	-	23
<input type="radio"/>	COM2	COM2	5002
<input type="radio"/>	COM3	COM3	5003
<input type="radio"/>	COM5	COM5	5005
<input type="radio"/>	COM6	COM6	5006
<input type="radio"/>	COM7	COM7	5007
<input type="radio"/>	COM8	COM8	5008
<input type="radio"/>	COM9	COM9	5009
<input type="radio"/>	COM10	COM10	5010
<input type="radio"/>	COM11	COM11	5011
<input type="radio"/>	COM12	COM12	5012
<input type="radio"/>	COM13	COM13	5013
<input type="radio"/>	COM14	COM14	5014
<input type="radio"/>	COM15	COM15	5015
<input type="radio"/>	COM16	COM16	5016


1. Select the port you would like to access.

Note: You must have permission in order to access a port.

2. If you want to view the port history, click the *View History* button. A screen showing the Telnet activity that took place on the device connected to the port appears. Click the browser's *Back* button to return to the Telnet page.

3. To access the device connected to the port, click **Connect**.

The JETPORT 5208 / JETPORT 5216 opens a Telnet session and a screen similar to the one below appears:



4. If you are connected to a computer and want to go to a terminal session or command line to operate it, Press **[Enter]**.


When you have finished with the session, **log out**, then bring up the Main Menu.

Note: Be sure to log out before bringing up the Main Menu, otherwise, another user can access the device without having to log in.


5. If you are connected to another device, enter the command that brings it up.

- To display the Suspend Menu, Press **[Ctrl+x]**.

Where **x** represents the Suspend Character set by the Administrator (see the *Property Settings* dialog box under *Port Configuration*, p. 27). The screen will prompt you as to the correct character. In this example, it is **[Ctrl+D]** (see the prompt on the previous screenshot). The following screen appears:



- Press **1** to issue a *Send Break* command to the attached device. This is used to put a Sun system in *OK Mode*.
- Press **Q** to bring up the Main Menu:



The Main Menu is the text based equivalent of the browser configuration and control functions. The descriptions and explanations for the Browser Operations apply to the submenu functions presented here, as well.

-
- Note:**
1. As with the browser version, access to many of these submenus are restricted to the administrator or users with configuration permission. If you select a submenu that you are not authorized for, nothing will happen.
 2. Some of the submenus do not have an *Exit* choice. In these cases, you can return to the previous menu without making any changes by pressing **Enter** twice.
 3. You can bring up the Main Menu at any time during your session.
-

When you have finished with your session, bring up the Main Menu and press **Q** to log out.

Port Configuration

Since only the administrator and users with port configuration permission can access this function, it is discussed in the Administration chapter.

User Manager

For users, clicking the *User Manager* button brings up a screen that shows their username, port configuration permission status, and the ports they are authorized to control:

User Manager			
Select	Login Name	Config	Ports
<input type="radio"/>	ronaldinho	Disabled	All

Clicking Edit brings up a dialog box that allows users to change their password and *Comments* information

User Information			
Username:	<input type="text" value="ronaldinho"/>	Comments:	<input type="text"/>
Password:	<input type="password"/>	Reenter password:	<input type="password"/>
<input type="button" value="Update"/>		<input type="button" value="Back"/>	

- § To save any changes, click **Update**.
- § To exit without saving any changes, click **Back**.

This Page Intentionally Left Blank

Chapter 6

Out of Band Operation

Overview

In case the network goes down, or the JETPORT 5208 / JETPORT 5216 cannot be accessed with the usual browser based method for some other reason, the JETPORT 5208 / JETPORT 5216 can be reached via several additional *Out of Band* (OOB) methods. These include HyperTerminal, PPP, Telnet, and SSH. Each of these is described in the sections that follow.

HyperTerminal

HyperTerminal is a program included with Windows. It can be used to establish either a direct terminal connection, or an indirect (phone in) terminal connection. Both configurations are discussed below.

Direct HyperTerminal Connection

Setup:

To set up a direct HyperTerminal connection, do the following:

1. Use Ethernet to serial cable to connect one of the JETPORT 5208 / JETPORT 5216's serial ports to a COM port on a PC.

Note:

1. In the examples that follow we use COM1. If you use a different COM port, change the settings accordingly.
 2. Be sure that the port you specify as the Console Port in the OOB dialog box matches the port that you are connecting the PC to. Change the setting, if necessary.
-


2. On your PC, run the HyperTerminal program:

Start → Programs → Accessories → Communications →
HyperTerminal → Hypertrm.exe


The following dialog box appears:



3. Key a name to describe the connection in the *Name* field (we chose Com1Test); select an icon to represent the connection; then click **OK**. A dialog box similar to the one below comes up:




- For the *Connect using:* field, select *Direct to COM1* (assuming you are using COM1 on your PC), then click **OK**. A *Port Setting* dialog box similar to the one below comes up:




- For OOB connections, the JETPORT 5208 / JETPORT 5216's serial port settings and the computer's COM port settings must be the same. Change the settings in your dialog box (if necessary), so that they match the JETPORT 5208 / JETPORT 5216's Console Port settings (see *Port Config* for details), then click OK.

Note: The JETPORT 5208 / JETPORT 5216's default settings are 9600 bps; 8 Data bits; No Parity; No Stop bits, but you can change these to something more suitable to your installation as long as they both match.

- When the HyperTerminal screen appears, open the File menu and select: Properties → Settings. The following dialog box displays:



- Change the settings (if necessary), so that they match the settings shown in the dialog box, then click **ASCII Setup...** The *ASCII Setup* dialog box comes up:



8. Change the settings (if necessary), so that they match the settings shown in the dialog box, then click OK.
9. Close the HyperTerminal Window. When Windows asks if you want to disconnect, click **Yes**. When Windows asks if you want to save the session, click **Yes**.

This completes the HyperTerminal setup. For Windows NT, 2000, XP and Windows Server 2003 systems, a HyperTerminal icon that connects you to the JETPORT 5208 / JETPORT 5216 is created on the desktop. For Windows 98 and ME, you must access HyperTerminal from the Windows Start Menu.

Logging In:


1. Double click the HyperTerminal icon on your desktop.
2. In the VT100 terminal window, key in:
`[Ctrl + D]`
A login prompt appears.
3. Key in your Username and Password to bring up the JETPORT 5208 / JETPORT 5216's main menu.

Indirect HyperTerminal Connection

This method uses HyperTerminal to phone into the JETPORT 5208 / JETPORT 5216 from a remote location.

Setup:

1. Set up your hardware configuration to match the diagram, below



§ On the remote computer side, use a standard 9 pin serial modem cable (pin 2 to pin 2; pin 3 to pin 3) to connect the computer to the modem.

§ On the JETPORT 5208 / JETPORT 5216 side, use Cat 5 cable and an

Note: Be sure that the port you specify as the Console Port in the OOB dialog box (see p. 22) matches the port that you connect the modem to. Change the setting, if necessary.

2. Create a HyperTerminal connection.
 - a) Start with Step 2 of the Direct HyperTerminal Setup section (p. 47).
 - b) For *Connect using*: in Step 4, select the type of modem connected to your computer from the list. If your modem doesn't appear in the list, select *Standard 28800bps Modem*.
 - c) Follow Steps 5-9 to complete the setup and create the connection icon.

This completes the HyperTerminal setup. For Windows NT, 2000, XP and Windows Server 2003 systems, a HyperTerminal icon that connects you to the JETPORT 5208 / JETPORT 5216 is created on the desktop. For Windows 98 and ME, you must access HyperTerminal from the Windows Start Menu.

Final Check:

To make sure that the modem and COM port are correctly installed:

1. Open the Control Panel:

My Computer → Control Panel


2. Open the *Make New Connection* folder.

If all went well, you should see an entry with the name you assigned for this connection.

3. Open the Device Manager:

My Computer → Control Panel → System → Device Manager

Your *Modem* and *Ports* entries should look similar to the image below



Logging In

1. Double click the HyperTerminal icon on your desktop.
2. In the VT100 terminal window, key in:

```
atdt [modem telephone number] [Enter]
```

The terminal responds with:

```
CONNECT115200
```
3. Wait at least 60 seconds, then key in:

```
[Ctrl+D]
```
4. Key in your Username and Password to bring up the JETPORT 5208 / JETPORT 5216's Main Menu.

PPP (Dial In) Connection

This type of connection works directly through the COM port.

Direct PPP Connection

Setup:

To set up a direct PPP connection, do the following:


1. Use Ethernet to Serial cable to connect one of the JETPORT 5208 / JETPORT 5216's serial ports to a COM port on a PC (refer back to the *PC Installation* section, if necessary).

Note: 1. In the examples that follow we use COM1. If you use a different COM port, change the settings accordingly.

2. On your PC, run the *Make New Connection* setup program:


Start → Programs → Accessories → Communications →
Make New Connection

The following dialog box appears:




3. Key a descriptive name for the connection in the top text box; select *Standard 28800 bps Modem* for the device; then click **Configure**.

- In the *Modem Properties* dialog box that comes up change the dialog box settings (if necessary), so that the COM port is correct, then click OK.




- Click the **Connection** tab to see the connection setup page:




- Change your settings (if necessary), so that they match the settings shown in the figure above then click **Advanced**.

7. In the *Advanced Connection Settings* dialog box enable *Use flow control*; select *Hardware (RTS/CTS)*; then click **OK** to return to the Connection page.



8. Click **OK** (at the bottom of the Connection page; then click **Next**. The following dialog box appears:



9. Key in anything you like for these fields, then click **Next**.
10. Click **Finish**.

A new icon that you can use to connect to the JETPORT 5208 / JETPORT 5216 is created in the *Dial-up Network* folder. This completes the Direct Dial In setup.

Finishing Up:

The JETPORT 5208 / JETPORT 5216's serial port settings and the computer's COM port settings must be the same. Change the JETPORT 5208 / JETPORT 5216's settings for the port you are connecting the computer to (see *Port Config*), so that they match the ones you just set in the dialog boxes (as shown in the table below):

Parameter	Value
Bit per second:	115200
Data bits:	8
Parity:	None
Stop bits:	1
Flow control:	Hardware (RTS/CTS)

Logging In:


1. Double click the icon you created in the *Dial-up Network* folder.
2. Key in your Username and Password, then click **Connect**.
3. Use Telnet, SSH, or your browser to access the JETPORT 5208 / JETPORT 5216 the same way as if you were accessing it over the net.

Indirect PPP Connection

This method uses a modem connection to phone into the JETPORT 5208 / JETPORT 5216 from a remote location.

Setup:

1. Set up your hardware configuration to match the diagram, below:



- § On the remote computer side, use a standard 9 pin serial modem cable (pin 2 to pin 2; pin 3 to pin 3) to connect the computer to the modem.
- § On the JETPORT 5208 / JETPORT 5216 side, use Cat 5 cable and an Optional: RJ-45 to Serial Cable

Note: Be sure that the port you specify as the Console Port in the OOBC dialog box matches the port that you connect the modem to. Change the setting, if necessary.

2. Set up your connection configuration as specified in Steps 2 - 8 of the *Direct Dial In Connection*, section.
3. For Step 9, key in the JETPORT 5208 / JETPORT 5216's modem telephone number in the fields provided, then click **Next**.
4. Click **Finish**.
A new icon that you can use to connect to the JETPORT 5208 / JETPORT 5216 is created in the *Dial-up Network* folder. This completes the Indirect Dial In setup.

Final Check:

To make sure that the modem and COM port are correctly installed, follow the procedures described under *Final Check* on p. 53.

Logging In:

1. Double click the icon you created in the *Dial-up Network* folder.
2. Key in your Username and Password; click **Connect** and wait for the Authentication procedure to complete (be patient, it may take a few moments).
3. Use Telnet, SSH, or your browser to access the JETPORT 5208 / JETPORT 5216 the same way as if you were accessing it over the net.

Telnet

Logging In

1. On your computer, open a terminal (command line) session.
2. At the prompt, key in the JETPORT 5208 / JETPORT 5216's IP Address in the following way:


```
telnet [IP Address]
```

Note: The default telnet port is 23. If that port is already being used, up to 16 additional users can log in by adding a port number (from 5000 to 5015) to the login command. For example:

```
telnet [IP Address]5001
```

3. Press **Enter**.

The following screen appears:



4. At the login prompt, provide your Username and Password.

Note: If you cannot see the login prompt click *Terminal/Preferences* on the telnet session's menu bar, then select *VT-100/ANSI*.

Once a Telnet connection to the device is established, the JETPORT 5208 / JETPORT 5216 Main Menu comes up. See p. 41 for Telnet operation.

SSH

Terminal Session (Linux):

1. Open a terminal (command line) on your computer.
2. At the prompt, key in your JETPORT 5208 / JETPORT 5216 Username and the JETPORT 5208 / JETPORT 5216's IP Address in the following way:


```
SSH [username@IP Address]
```

Note: The default SSH port is 22. If that port is already being used, up to 16 additional users can log in by adding a port number (from 5100 to 5115) to the login command. For example:

```
SSH [username@IP Address] -P 5101
```

3. Press **Enter**
4. When you are prompted for a password, use your JETPORT 5208 / JETPORT 5216 password.

Once an SSH connection to the device is established, the JETPORT 5208 / JETPORT 5216 Main Menu comes up:




This menu is the same as the main menu that appears with Telnet sessions (see p. 41 for Telnet operation).

Third Party Utility (Windows):

SSH sessions can be implemented under Windows with the use of third party utility software, such as PuTTY, a free implementation of Telnet and SSH for the Win32 and Unix platforms. To make an SSH connection with PuTTY, do the following:

1. In the *Host Name* box, enter the Internet host name of the server you want to connect to.

Note: The default SSH port is 22. If that port is already being used, select an alternate port - from 5100 to 5115. This allows up to 16 additional users to log in at the same time.



2. Select *SSH* from the Protocol buttons.
3. Click **Open** (at the bottom of the dialog box)
4. After you have connected, provide your JETPORT 5208 / JETPORT 5216 username and password at the login prompts.

Note: If you make a mistake keying in the username, the SSH protocol doesn't allow you to try again. You must close PuTTY and start over.

Once an SSH connection to the device is established, the JETPORT 5208 / JETPORT 5216

Main Menu comes up. This menu is the same as the main menu that appears with Telnet sessions (see p. 41 for Telnet operation).

This Page Intentionally Left Blank

Chapter 7

Real Port Management

Overview

The JETPORT 5208 / JETPORT 5216 offers *Real COM Port* support. Devices connected to this type of Real port appear as if they were directly connected to a COM port on the local computer. Data transmission between the device and the local computer takes place over the Real COM port to the JETPORT 5208 / JETPORT 5216.

This mode is useful with serial devices such POS terminals, Bar Code Readers, Serial printers, etc. In addition, this mode can be used with other Korenix management products.


Driver Installation

In order to utilize Real COM port management, the Korenix Real COM port driver must be installed. To install the driver, do the following:

1. On the software CD that came with your JETPORT 5208 / JETPORT 5216 package, locate the file: *Real_Port_vxxx.exe*

Note: The *vxxx* specified above stands for the driver's version number. The file on the CD will show an actual version number.

2. Double click the filename to start the installation. The Setup screen appears:




Click **Next** to move on.

3. Click **Yes** to accept the License Agreement.
4. Continue through the setup screens to complete the driver installation.

Real Port Management

The Real Port Management Utility provides a convenient interface to COM port mapping. When you run the *Real Serial Port Manager* program (Start → Real Port Management Utility → Real Serial Port Manager), the following dialog box appears:



Dialog Box Layout

The Real Port Management Utility dialog box is laid out as follows:

- § The menu and button bars allow the automatic enumeration and listing of devices and ports.
- § Below the menu and button bars, there is an area to input information in order to manually list target devices if the device doesn't appear using the automatic enumeration method.
- § All target devices that were found by enumeration or manually entered are listed in the left side panel.
- § All ports that were found for a selected target device are enumerated in the central panel.
- § The right side panel displays the Real COM port mappings that you have made.

Menu and Toolbar

The Real Port Management Utility menu and toolbar have the same captions and functions. Users can either click the menu items or buttons to invoke the desired function, as shown in the table, below:

Item	Action
Enum Targets	This function searches and lists all SN01xx devices on the LAN. The results are shown in the Target List panel (see <i>Target List</i> for details). Be aware that all devices listed in the Target List will be deleted when the delete function is invoked. Be sure to remove any devices from the list that you don't want to delete before invoking the delete function.
Enum Ports	This function lists the existing ports for the target device currently selected in the Target List. The results are shown in the Port List panel.
Map	After selecting a port from the <i>Port List</i> panel, selecting this function maps the device's COM port to a Real COM port on the user's computer.
Unmap	After selecting a port from the <i>Mapped Ports</i> list, selecting this function removes the mapping between the computer and the device's COM port.


Target Information

The Target Information fields allow a user to install (map) ports on an offline target device, as follows:

Field	Action
Target IP Address	Input the IP address of the target that you want to map COM ports to.
Base Socket Port	The base socket port of the target device.
Target Name	The name of the target. If it is different from the target's real name, it will be replaced by the real one. Note that the name is not related to the mapping or unmapping process. Only the IP address, socket port and target type are relevant.
Target Type	The type of target to be mapped. Only SN01xx series devices are valid.
Add Target	Creates an entry in the Target List based on the above information.
Delete Target	Remove the currently selected target from the Target List.

Target List

The left side panel displays all the devices that were found with the *Enumeration* function, as well as any devices that were manually added with the *Target Information* fields.




Note: Double clicking an item in the list invokes the same function as selecting **Enum Ports**—which displays the numbers and working modes of the selected target's ports in the *Port List* column.

- § If a device was automatically listed as a result of the *Enumeration* procedure, the icon to its left is drawn with green dots and lines to show that the target is on line and is ready to be mapped.
 - § If a device was added to the list manually and is off line, the icon to its left is drawn with black dots and lines. Double clicking a manually added item can get some information and display it in the *Port List*, but the working mode information is not accurate and we must assume that all the device's ports are in Real Port mode. See *Operating Mode* for details about port modes.
 - § If the target is off line or is on line but does not respond within 2 seconds of asking to enumerate its ports, the working mode information is not accurate and we must assume that all the device's ports are in Real Port mode. See *Operating Mode* for details about port modes.
-

Port List

This list displays the port information of the selected target (only one target can be selected at a time).



- § The left column lists the target's port numbers, the second column shows the COM port it is mapped to (if any), the third column shows its working mode, and the right column shows its status.


Note: The working mode refers to the setting for the port that was specified when the port was configured. See *Port Config* for details.

- § Double clicking a port in the Port List brings up a *Port Mapping* dialog box that lets users select the number of COM ports they wish to map (i.e., Real COM ports they wish to install). Only ports designated as *Real Port* ports can be mapped. See *Port Mapping* for mapping details.

Note: The *Port Mapping* dialog box can also be invoked either by clicking MapTo... on the toolbar or selecting MapTo... from the menu.

Mapped COM Ports

This panel displays the mapped COM ports, showing the device and port that each mapped one is derived from. The list is generated as soon as the application starts, and is dynamically updated whenever the mapped COM port configuration changes as a result of installations and removals.




Port Mapping and Unmapping

Port Mapping

To map a Real COM port:

1. Double click your Target item in the Port List to bring up the *Port Mapping* dialog box:



2. Drop down the list of available COM ports and select the COM port you wish to map the Target port to.
3. Click **OK** to complete the operation.


Note: 1. If a range of ports was selected, and *Map consecutively* is enabled, the COM ports are mapped to the Target ports in sequence based on the port numbers.

2. Only *Real Mode* ports are mapped. Other ports in the range are passed over.
-

Port Unmapping

To unmap Real COM ports:

1. Either click **Unmap...** on the button bar or select *Unmap...* from the menu to bring up the *Port Unmapping* dialog box:



2. Drop down the list of mapped COM ports and select the COM port you wish to unmap.
3. Click **OK** to complete the operation.

Note: For a consecutive unmapping, the COM ports are unmapped in sequence based on the mapped COM port number.

Appendix

Specifications

Specification

Technology

Standard: IEEE802.3 10Base-T
IEEE802.3u 100Base-TX
IEEE802.3x flow control

Serial Communication

Number of Ports: 8
Interface: RS-232
Connectors: RJ45
Data Rates: 115.2 bps
Data Bits: 5, 6, 7, 8
Parity: odd, even, none
Stop Bits: 1, 1.5, 2
RS-232: TxD, RxD, RTS, CTS, DTR, DSR, GND, DCD
Flow Control: XON/XOFF, RTS/CTS, DTR/DSR
Serial Line Protection: 15KV ESD

Network Communication

Connector: RJ-45
Feature: Auto MDI/MDI-X, 10/100M Auto-Negotiation

Other

LED
PWR: Startup(Blue); Ready(Green)
Ethernet Link: Green
100M/10M Link: 100M Link(Green)/10M Link(Orange)
Serial: Green

Software

Configuration: Windows Utility, HTTPS, SSH, Telnet, SNMP, DHCP Client, Device Password, Firmware Upgrade, Save to Flash

Group Configuration Wizard:

Group IP Wizard, Group firmware upgrade, Group Backup/Restore, VCOM and TCP Tunnel Setup Wizard

MIB: RFC1213 MIB II, RFC1317 RS232_like

SNMP Trap: Send Trap for pre-defined Traps

SNTP: For time management

Serial Service Mode: Real COM, TCP Server

Advanced Setting: Port-Specific access right, Direct port addressing- via SSH to any Serial Over IP port, Direct Access via serial applications or IP application, VT320 support

Monitor: Devices' status, session history

E-Mail Alert: Automatic e-mail warning by pre-defined events

Power Requirements

System Power: 100-240 VAC

Power Consumption: 8Watts /120VAC, 230VAC

Mechanical

Installation: Rackmount

Dimension: 43.72 x 21.40 x 4.40 cm (1U/19")

Net Weight: 3.30kg/3.40kg

Environmental

Operating Temperature: 0 ~ 50°C

Operating Humidity: 5% ~ 95%, (non-condensing)

Storage Temperature: -20 ~ 60°C

Storage Humidity: 5%~ 90%, (non-condensing)

Regulatory Approvals

EMI: FCC Class A, CE/EN55022.

EMC Immunity Interface:

EN61000-4-2, EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-8, EN61000-4-11

Safety: CE/EN60950

Shock: IEC60068-2-27

Vibration: IEC60068-2-6

Free Fall: IEC60068-2-32

Ordering Information

JetPort 5208/5216 8/16 port Rackmount Serial Device Server

Includes:

- JetPort 5208/5216
- Quick Installation Guide
- 100-240VAC power adapter
- Din-Rail kit and foot pads
- Documentation and Software CD-ROM


Optional Accessory

- Serial cable (RJ45 to DB9 male, 150cm)

Administrator Login Failure

If you are unable to perform an Administrator login (because the Username and Password information has become corrupted, or you have forgotten it, for example), you can clear the login information with the following procedure:

1. Power off the JETPORT 5208 / JETPORT 5216 and remove its housing.
2. Short the jumper labeled J6.



3. Power on the switch.
4. When the Link and 10/100Mbps LEDs flash, power off the switch.
5. Remove the jumper cap from J6.
6. Close the housing and start the JETPORT 5208 / JETPORT 5216 back up. After you start back up, you can use the default Username and Password to log in.


IP Address Determination

If you are an administrator logging in for the first time, you need to access the JETPORT 5208 / JETPORT 5216 in order to give it an IP address that users can connect to. There are three methods to choose from. In each case, your computer must be on the same network segment as the JETPORT 5208 / JETPORT 5216. After you have connected and logged in you can give the JETPORT 5208 / JETPORT 5216 its fixed network address.

Method 1:

For computers running Windows, an IP address can be assigned with the IP Installer utility:

1. Unzip the contents of IPInstaller.zip (found on the Software CD that came with your JETPORT 5208 / JETPORT 5216 package) to a directory on your hard drive.
2. Go to the directory that you unzipped the IPInstaller program to and run IPInstaller.exe. A dialog box similar to the one below appears



3. Select the JETPORT 5208 / JETPORT 5216 in the *Device List*.

Note: 1. If the list is empty, or your device doesn't appear, click **Enumerate** to refresh the Device List.

2. If there is more than one device in the list, use the MAC address to pick the one you want. The JETPORT 5208 / JETPORT 5216's MAC address is located on its bottom panel.
-

4. Select either *Obtain an IP address automatically (DHCP)*, or *Specify an IP address*. If you chose the latter, fill the IP Address, Subnet Mask, and Gateway fields with the information appropriate to your network.
5. Click **Set IP**.
6. After the IP address shows up in the Device List, click **Exit** to end the program.

Method 2:

1. Set your computer's IP address to 192.168.10.XXX
Where XXX represents any number or numbers except 10. (192.168.0.10 is the default address of the JETPORT 5208 / JETPORT 5216.)
2. Specify the switch's default IP address (192.168.10.2) in your browser, and you will be able to connect.
3. Assign a fixed IP address for the JETPORT 5208 / JETPORT 5216 that is suitable for the network segment that it resides on.
4. After you log out, be sure to reset your computer's IP address to its original value.

Method 3:

A fixed IP address can also be assigned with the ARP command as follows:

1. Turn off the power to the JETPORT 5208 / JETPORT 5216.
2. Enter the following command:

```
arp -s <ip address> <JETPORT 5208 / JETPORT 5216's MAC  
address>
```

Where the IP address that you assign is one suitable for the network segment that the JETPORT 5208 / JETPORT 5216 resides on.

Note: The JETPORT 5208 / JETPORT 5216's MAC address can be found on its bottom panel.

3. Turn the power to the JETPORT 5208 / JETPORT 5216 back on.
4. In your browser, go to the IP address you just assigned and log in with your Username and Password.

Note: You must log in within 30 seconds after entering the arp command. Therefore, it would be advisable to have your browser all set up to go to the IP address beforehand.

5. Once you have logged in, go to *Network*, to set up the permanent IP environment.

Pin Assignments

RJ45-F to DB9-F

DTE to DTE

JETPORT 5208 /	Pins (8)		Computer (DB9)
RTS	1	←————→	8
DTR	2	←————→	6&1
TXD	3	←————→	2
CTS	4	←————→	7
GND	5	←————→	5
RXD	6	←————→	3
DSR	7&8	←————→	4
9 NC not used			

RJ45-F to DB9-M

DTE to DCE

JETPORT 5208 / JETPORT 5216 (RJ45)	Pins (8)		Modem/Device (DB9)
RTS	1	←————→	7
DTR	2	←————→	4
TXD	3	←————→	3
CTS	4	←————→	8
GND	5	←————→	5
RXD	6	←————→	2
DCD	7	←————→	1
DSR	8	←————→	6
9 NC not used			

RJ45-F to DB25-F

DTE to DTE

JETPORT 5208 /	Pins (8)		Computer (DB25)
RTS	1	←————→	5
DTR	2	←————→	6&8
TXD	3	←————→	3
CTS	4	←————→	4
GND	5	←————→	7
RXD	6	←————→	2
DSR	7&8	←————→	20
Other pins not used			

RJ45-F to DB25-M

DTE to DCE

JETPORT 5208 / JETPORT 5216 (RJ45)	Pins (8)		Modem/Device (DB25)
RTS	1	←————→	4
DTR	2	←————→	20
TXD	3	←————→	2
CTS	4	←————→	5
GND	5	←————→	7
RXD	6	←————→	3
DCD	7	←————→	8
DSR	8	←————→	6
Other pins not used			

RJ45-F to DB9-M

DTE to DTE

JETPORT 5208 /	Pins (8)		Computer (DB9)
RTS	1	←————→	8
DTR	2	←————→	6&1
TXD	3	←————→	2
CTS	4	←————→	7
GND	5	←————→	5
RXD	6	←————→	3
DSR	7&8	←————→	4
9 NC not used			

RJ45-F to DB9-F

DTE to DCE

JETPORT 5208 / JETPORT	Pins (8)		Modem/Device (DB9)
5216 (RJ45)			
RTS	1	←————→	7
DTR	2	←————→	4
TXD	3	←————→	3
CTS	4	←————→	8
GND	5	←————→	5
RXD	6	←————→	2
DCD	7	←————→	1
DSR	8	←————→	6
9 NC not used			

RJ45-F to DB25-M

DTE to DTE

JETPORT 5208 /	Pins (8)		Computer (DB25)
RTS	1	←————→	5
DTR	2	←————→	6&8
TXD	3	←————→	3
CTS	4	←————→	4
GND	5	←————→	7
RXD	6	←————→	2
DSR	7&8	←————→	20
Other pins not used			

RJ45-F to DB25-F

DTE to DCE

JETPORT 5208 / JETPORT 5216 (RJ45)	Pins (8)		Modem/Device (DB25)
RTS	1	←————→	4
DTR	2	←————→	20
TXD	3	←————→	2
CTS	4	←————→	5
GND	5	←————→	7
RXD	6	←————→	3
DCD	7	←————→	8
DSR	8	←————→	6
Other pins not used			

Revision History

Version	Description	Date
V1.0	The first released version.	Feb. 2009

